



Installing MacBook Pro 15" Unibody Mid 2009 Lower Case

Tools used in this guide

- [Phillips #00 Screwdriver](#)

Parts relevant to this guide

- [MacBook Pro 15" Unibody \(Mid 2009\) Lower Case](#)



Step 1 - Lower Case

- Remove the following ten screws securing the lower case to the upper case:
 - Seven 3 mm Phillips screws.
 - Three 13.5 mm Phillips screws.



Step 2

- Using both hands, lift the lower case near the vent to pop it off two clips securing it to the upper case.
- Remove the lower case and set it aside.

